Washing Machine Float Switch (J60-220)

`Model: J60-220`



Category: Washing Machines

Washing machine float switch, model J60-220, with white plastic body, metal collar, T-shaped float paddle, and 3-pin connector.

DESCRIPTION

This washing machine float switch, model J60-220 (printed directly on the housing), has a white plastic body with a metal collar ring and a T-shaped plastic float paddle that pivots to trigger the switch contacts. Inside, a 3-pin blue connector block wires the switch into the machine's control circuit. It mounts through a panel cutout and senses water level by the float paddle's position.